

Adapter Instructions

For use with
Draeger X-plore Respirators

Please follow instructions when using OHD Adapter Kit #30 with the Draeger X-plore series that has the twist-lock bayonette connection.

To prep the respirator, you must remove or prop open the inhalation valve on the side of the mask that will receive the adapter piece with the two connectors. To prop open the valve, you can use the OHD valve prop. (see image below)

Kit #30 will twist-lock onto both sides of the mask, just be sure to put the dual connector part on the side of the mask with the propped open valve.

Connect the blue tube to the single connector, and the clear tubes to either connector on the side with dual connectors. The respirator is now ready to be tested.



An example of propping open a valve on a different mask with the OHD valve prop.