



**Fit Test Adapter
Kit #1
For SCBA and Gas Masks**



OHD Fit Test Adapter | Kit #1



Fig. 1



Fig. 2

INSTRUCTIONS:

1. If there is an inhalation valve inside the mask where the filter or cartridge screws in, prop it open or remove (Fig. 1)
2. Screw the Kit #1 adapter clockwise into the mask opening until it is firmly hand tight.
3. Connect the clear tubes to the dual ports on the side, and the single blue tube to the single port on the top (Fig. 2)
4. Perform fit test
3. If the diaphragm should leak, remove 8 screws on top, carefully line up new diaphragm, screw in the screws loosely. Tighten opposite sides until all are secure.
4. Adapters may be cleaned with soapy water and soft cloth.
5. Adapters can be disinfected by spraying a disinfectant between tests or immersed in a cleaning solution and left out to dry. (The adapters allow outside air to be inhaled, but an employee's exhalation is routed through the exhalation valve nullifying the risk of cross-contamination.)

CARE:

1. The adapters should be handled with care so as not to create damage that might interfere with testing.
2. Periodically check the metal hose connectors to be sure they are secure.