

# QuantiFit<sup>2</sup> VIRTUAL OPERATOR

---

## HARD-TO-FIT GUIDE

VIRTUAL OPERATOR GAS MASK FIT TESTING

### CHECK THE TEST SUBJECT

- Check facial hair – there cannot be any facial hair that impedes the seal.
- Check hair placement – there cannot be any hair that crosses the seal.
- Is the test subject holding their breath steadily?
- Ensure the person is not actively moving during the test.

### CHECK THE RESPIRATOR

- Is the respirator on correctly? Check straps and placement.
- Is the respirator an appropriate size?
- Is the respirator in good condition? A crack in the lens, a dirty exhalation valve, or a problem with the seal can all lead to failures.

### CHECK COMPONENTS

- Adapter
- Triple tube assembly

### CONTACT OHD

- If you are still having trouble, please contact OHD Tech Support at:

[USAFSupport@ohdglobal.com](mailto:USAFSupport@ohdglobal.com)

